

Welcome to Roam Mobility.

With the Liberty Mobile Hotspot, you have the power of the Internet in your back pocket. Staying in touch and staying productive while traveling in the US has never been so easy.

Follow the simple steps in this guide, and you'll enjoy a super-fast and reliable connection to the Internet, at prices 99% less than other providers*.

If you need help with the service, check out the support centre at www.roammobility.com/support

For more specific help, or to talk to a live agent call Customer Care at 1-888-ROAM 4US (762-6487)



Let's get going!

- 1 Activate online**
www.roammobility.com/activate
- 2 Purchase a data plan and set the start date**
www.roammobility.com/plans
- 3 Travel to the US**
Service only available in US
- 4 Insert Sim Card**
Beneath the battery
- 5 Write down the SSID and password**
On the sticker behind battery
- 6 Turn the device on**
It will broadcast a wireless signal
- 7 Connect Wi-Fi enabled devices to the wireless signal**
Using the SSID and password you wrote down
- 8 You're ready to go**

Good to know.

Before you head south, here's some handy info for you to know:



Power up:

Although your Liberty Mobile Hotspot comes with a partial charge, we recommend you fully charge it before traveling so you don't get caught short. You can charge the device from the main adaptor, or use the USB adaptor that connects to your computer. To power up or shut down your device, simply hold down the power button for a few seconds.



Connect to your Liberty Mobile Hotspot:

You can connect up to five devices to the Internet simultaneously through the Liberty Mobile Hotspot. Each device connects to the wireless signal using the same SSID and password. You cannot connect to the Internet through the USB cable. Please note that if you can't see the wireless signal, your Liberty Mobile Hotspot may have gone into sleep mode. Briefly press the power button to re-broadcast the signal.

Device indicators:

- Indicates Wi-Fi signal strength and how many devices are connected via Wi-Fi.
- Sleep mode, Wi-Fi is not broadcasting.
- Network signal strength.
- 4G** Indicates that your Liberty Mobile Hotspot is on the 4G network.
- 3G** Indicates that your Liberty Mobile Hotspot is on the 3G network.
- E** Indicates that your Liberty Mobile Hotspot is connected to EDGE.
- G** Indicates that your Liberty Mobile Hotspot is connected to GPRS.
- Battery power level. The indicator will flash when the battery is almost exhausted.

Monitor usage:

Log into your account anytime at www.roammobility.com to see details of your current and previous plans.

We'll let you know via email when you're nearing the end of your plan so you never get stranded. Remember, you can never go over your limit because all our data plans are pre-paid.

Top up:

Top up by logging into your account at www.roammobility.com. You will be asked to schedule the start of your new plan to coincide with the end of your current one, start immediately, or start on a specific date in the future.



Change SSID and password:

To connect Wi-Fi-enabled devices, you can use the default SSID and password printed on the label in the battery compartment of your Liberty Mobile Hotspot, or you can choose to set your own.

1. Connect your computer to your Liberty Mobile Hotspot via Wi-Fi.
2. On your computer, open a browser window and enter <http://liberty.hotspot> in the Web Address field.
3. In the Password field, enter your password and click Login. (NOTE: The default password is "admin").
4. At the Change SSID and Password screen, enter a new SSID name and password then click Apply.
5. Click Apply once more; then click OK and you're done.

Change Administrator password:

1. Connect your computer to your Liberty Mobile Hotspot via Wi-Fi.
2. On your computer, open a browser window and enter <http://liberty.hotspot> in the Web Address field.
3. In the Password field, enter your password and click Login (NOTE: The default password is "admin").
4. Click Advanced.
5. Click Management; then in the Current Password field enter your existing administrator password. In the New Password and Verify Password fields, enter your new administrator password.
6. Click Apply and you're done.

Memory card:

The Liberty Mobile Hotspot comes with a microSD slot, enabling you to store music, pictures, and other files on your device. Simply purchase a microSD memory stick and insert it into the memory card slot. Then connect to a computer via USB to transfer files.



Reset to factory default:

Resetting to factory default settings will reset your Liberty Mobile Hotspot to the default SSID and password. The default SSID and password are printed on a label behind the battery.

1. Press and hold the WPS and Power keys simultaneously.
2. Hold for about three seconds or until the display and all LEDs are off.
3. Release the keys. The Liberty Mobile Hotspot will restart automatically and you will see "Resetting" on the display.

Your US phone number:

Even though you're using a data-only plan with the Liberty device, you will be assigned a US number when you activate your device online. The number will be sent to you via email and you can retrieve it by logging into your account at any time.

Should you wish to use your SIM card in a talk and text enabled device, simply purchase an appropriate plan at www.roammobility.com/plans and insert the SIM card into the new device. Your US number will now be functional, and you'll be able to make calls throughout the US and Canada for as little as \$2 per day.

Data plans:

Amount	Cost
500 MB	\$29.95
1 GB	\$39.95
2 GB	\$59.95
5 GB	\$99.95

All data plans are valid for 30 days from activation.
See data calculator at www.roammobility.com/datacalculator



Start Guide

Liberty Mobile Hotspot

Please see Roam Mobility Service Terms of Use at: www.roammobility.com/servicejou

See our Fair Usage Policy at: www.roammobility.com/servicefup

Details of the manufacturer's limited warranty available at: www.roammobility.com/libertywarranty

* Compared to other major Canadian carriers